What is OFFSETGAPTYPE variable?

This system variable can have a drastic effect on the appearance of offsets. It"s stored in the registry so it affects all drawings. The initial value is 0.

- 1 Fills the gaps with a filleted arc segment (the radius of the arc segment is equal to the offset

    distance)

- 2 Fills the gaps with a chamfered line segment

Online URL: https://kb.gstarcad.com.my/article/what-is-offsetgaptype-variable-1128.html