PUBLISHCOLLATE system variable

Function Description:

The **PUBLISHCOLLATE** system variable is used to control whether it could be interrupted by other print tasks when plot sheet set, multiple pages files, or plot spool files.

Type : Integer
Saved in : User-setting
Initial value : 1
Range : 0,1

System Variable Value:

0 : a published sheet set is processed one sheet at a time. Creating a single PLT file for each drawing. If the sheet set is published, the sheets might be interleaved with other plot task.
1 : a published sheet set is processed as a single task. A multiple pages PLT file is created. If the sheet set is published, the sheets might be not interleaved with other plot task.

Online URL: https://kb.gstarcad.com.my/article/publishcollate-system-variable-1782.html