XREFTYPE system variable

1932 GstarCAD MY /KW July 28, 2021 System Variables 0 763

Function Description:

The **XREFTYPE** system variable is used to control the default reference type when attaching or overlaying external reference.

Type : Integer
Saved in : Registry
Initial value : 0
Range : 0,1

System Variable Value:

0 : attachment is the default
1 :overlay is the default

Online URL: https://kb.gstarcad.com.my/article/xreftype-system-variable-1932.html