MEASUREINIT system variable

1700 GstarCAD MY /KW July 21, 2021 System Variables 0 784

Function Description:

The **MEASUREINIT** system variable is used to control whether a drawing started from scratch using imperial or metric default settings.

Type : Integer
Saved in : Registry
Initial value : Vary by country /region
Range : 0,1

System Variable Value:

0 : imperial
1 : metric

Online URL: https://kb.gstarcad.com.my/article/measureinit-system-variable-1700.html