

# Rotate Cursors

1050 GstarCAD Malaysia June 30, 2021 [Unique function](#) 0 3788

The cursor can rotate anti-clockwise by 0 degree or 45 degree.

**Menu :** Express > GstarCAD Tools > Rotate Cursor > 0 or 45

**Command Entry :** RTCUR0/RTCUR45 (0 degree/45 degree)

## Side Line

**Menu :** Express >GstarCAD Tools > Rotate Cursor > Side Line

**Command Entry :**RTCUR1

## Operation steps:

- 1.Start the command.
- 2.Select the reference segment and system will align the X axis of the cursor to the selected segment.

## Real Time Rotate

**Menu :** Express > GstarCAD Tools > Rotate Cursor > Real Time Rotate

**Command Entry :** RTCUR

## Operation steps:

- 1.After executing the command, the command line prompts as below.



Command: \_rtcur  
Counterclockwise coarse (A) / clockwise coarse (D) / counterclockwise Fine Tuning (W) / clockwise Fine Tuning (S) / normal (0):0  
428.5126,132.3789,0 SNAP GRID ORTHO POLAR OSNAP OTRACK LWT DYN MODEL

- 2.You can use the AWS4 keys to control the cursor direction until you are satisfied and press enter.

Online URL: <https://kb.gstarcad.com.my/article/rotate-cursors-1050.html>

