

LENSLENGTH system variable

1662 GstarCAD MY /KW July 19, 2021 [System Variables](#) 0 881

Function Description:

The **LENSLENGTH** system variable is used to store the length of the lens in millimeters used in perspective viewing.

Type : Real

Saved in : Drawing

Initial value : 50.000

Online URL: <https://kb.gstarcad.com.my/article/lenslength-system-variable-1662.html>