

PREVIEWFILTER system variable

1765 GstarCAD MY /KW July 23, 2021 [System Variables](#) 0 568

Function Description:

The **PREVIEWFILTER** system variable is used to exclude specified object types from selection preview.

Type : Bitcode

Saved in : Registry

Initial value : 7

Range : 0 ~ 63

The setting is stored as a bitcode using the sum of listed system variable values.

System Variable Value:

- 0 : exclude nothing
- 1 : exclude objects on locked layers
- 2 : exclude objects in xrefs
- 4 : exclude tables
- 8 : exclude Mtext objects
- 16 : exclude hatch pattern objects
- 32 : exclude objects in groups

Online URL: <https://kb.gstarcad.com.my/article/previewfilter-system-variable-1765.html>