

# ARX command

1972 GstarCAD MY /KW August 2, 2021 [CAD Commands](#) 0 824

The **ARX** command is used to load, unload Object ARX application program and provide related information.

## Command Access:

**Command :** ARX

## Command Prompts:

Enter options [File/Group/Command/CLass/Service/Load/Unload]::

## Relative Glossary:

### File:

List current loaded object ARX application program, it could be the third party program or internal application program (such as Render).

### Group:

Make the specified command group as the firstly searched one when users are interpreting command names.

### Command:

List AcEd registered commands.

### CLass:

Display C++ hierarchical structure defined by registered objects in system.

### Service:

List all names of registered service.

### Load:

Display “ObjectARX/DBX file” dialog box. Users could use this option to load specified ObjectARX application programs.

### Unload:

Unload specified ObjectARX application programs.

Online URL: <https://kb.gstarcad.com.my/article/arx-command-1972.html>