

# **-GROUP command**

2141 GstarCAD MY /KW August 16, 2021 [CAD Commands](#) 0 1023

The **-GROUP** command is used to create and manage the saved object group.

## **Command Access:**

**Command :** -GROUP

## **Command Prompts:**

Enter group option [?:Order/Add/Remove/Explode/REName/Selectable/Create] :

## **Relative Glossary:**

### **?:**

List names and descriptions of groups defined in the drawing.

### **Order:**

Change the numerical order of objects in the group.

### **Reorder:**

Users could specify the position number of objects to recorder all members in the group.

### **Reverse order:**

reverse the order of all members in the group.

### **Add:**

Add objects to a group.

### **Remove:**

Remove objects from a group. The group definition still exist even if all objects in group removed. They could be removed by Explode option.

### **Explode:**

Explode the group into its component objects to delete a group definition.

### **Rename:**

Assign a new name to an existing group.

### **Selectable:**

Specify whether a group is selectable. When it is selectable, selecting one object in the group selects the whole group. Objects on locked or frozen layers are not selected.

### **Create:**

Create a group. Group names could contain letters, numbers, and special characters such as dollar sign (\$), hyphen(-), and underscore(\_) but spaces. The name of a group is up to 31 characters long and they will be converted to uppercase characters.

Online URL: <https://kb.gstarcad.com.my/article/group-command-2141.html>