RENDER command

The **RENDER** command is used to create real photo images or real color images for 3D solids or surface models.

Command Access:

Menu : View > Render > Render
Command : RENDER

Command Prompts:

Regenerating model.

Function Description:

This command could start the rendering process and display the rendered images. By default, it will render all objects in current view. The current view will be rendered if no named view or camera view specified.
Inputting "-render" under the prompt, it will display options.

Online URL: https://kb.gstarcad.com.my/article/render-command-2329.html