# **Control Dimension Geometry**

2565 GstarCAD MY /KW November 9, 2021 Workflow 0 671

The appearance of dimension lines, extension lines, arrowheads and center marks can be managed

C Override Current Style: STANDARD	
Lines Symbols and Arrows Text Adjust Primary Units Alternate Units Tolerance	
Arrows	
First:	- Lever Leve
Closed filled	1.0159
Second:	
Elosed filled	1.1955
Leader:	2.0208
Closed filled 🗸	
Arrow size:	R0.8045
0.1800	
Center marks	Arc Symbol
⊘ None	<ul> <li>Preceding dimension text</li> <li>Above dimension text</li> </ul>
Mark 0.0900	None
© Line	
	Radius jog dimension
Dimension Break	Jog angle: 45
Break size:	Linear jog dimension
0.1250 🚖	Jog height factor:
	1.5000 Text height
OK Cancel Help	

## **Control Dimension Lines**

Controlling the dimension line properties like color, lineweight and spacing .

## **Control Extension Lines**

Controlling the extension line properties like color, lineweight, overshoot and offset length.

## **Control Dimension Arrowheads**

Controlling the arrowhead symbol's type, size and visibility in dimensions and leaders .

#### **Customize Arrowheads**

You can create your own custom arrowheads by defining a block.

To use custom arrowhead, select Use Arrow option in the list of arrowhead and specify the name of the block definition.

Online URL: https://kb.gstarcad.com.my/article/control-dimension-geometry-2565.html